

LOADBAR WIDE® REMOVAL INSTRUCTIONS

METHOD 1



Use forklift



Place fork under/near pocket*



Slowly lift to remove

* Use caution to not damage freight

METHOD 2



Score channels



Insert prybar



Pry open



Pry up 2x4



Use prybar and handle

OR



Use 2x4 to pry off wall



Scan for video



Innovators of Freight Securement Systems®

800-758-5840
www.logistick.com

Revised May 2017
L. 21 c